


Truss Mate 2

User Manual



Truss Mate 2

www.showtech.com.au

Truss Mate 2

Table of Contents

1. Safety instructions.....	3
1.1 Overhead rigging	4
1.2 Power Connection	6
1.3 Cleaning and Maintenance	6
2. Menu Navigation	7
3. DMX Allocation	9
4. Technical Specifications	11

Truss Mate 2

1. Safety Instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature.

Avoid exposing it to direct rays of sun near a heating appliance.

Do not put it in a temperature below 41°F/5°C, or exceeding 95°F/35°C.

Keep away from humidity, water and dust.

Do not place the set in a location with a high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

NO USER SERVICABLE PARTS INSIDE.

If unit is out of service please contact your point of purchase.

Truss Mate 2

If any troubles arise, remove the power plug and contact your Pro Shop representative for repair. Do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable. Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug.

When not using the unit for an extended period of time be sure to disconnect the plug from the receptacle.

1.1. Overhead Rigging

This item must be built in a way that it can hold 10 times more of its weight for 1 hour without causing any damages. The installation must be secured with a secondary safety attachment. The Safety attachment has to be constructed in a way that no part of the installation can fall down. When rigging, de-rigging or servicing the fixture staying in the area below the installation place, on bridges, under high working places and other endangered areas is forbidden. Before taking the device in operation, the installation must be approved by an expert. The operator has to make sure that safety-relating and machine-technical installations are approved by a skilled person once a year.

IMPORTANT! OVERHEAD RIGGING REQUIRES EXTENSIVE EXPERIENCE.

Including (but not limited to) calculating working load limits, installation material being used, and periodic safety inspection of all installation material and the projector. If you lack these qualifications, do not attempt the installations yourself, but instead use a professional structural rigger. Improper installation can result in bodily injury and/or damage to property.

Truss Mate 2

IMPORTANT:

If multiple PixPad panels are being rigged together as a larger system, special care must be taken to ensure total loads are adhered to. A maximum of 10 panels should be hung under each other, longer drops require further bracing or load support, please refer to a qualified expert. Horizontally mounted panels should also be picked up from a minimum of every second panel to properly spread the load.

Use only professional trussing system if the item shall be lowered from the ceiling or high joists. Never let the device swing freely in a room.

CAUTION: Overhead Items may cause serious injuries when crashing down!! If there is concern about the safety then **DO NOT INSTALL** the device.

DANGER OF FIRE!

When installing the device, make sure there is no highly-flammable material (decoration articles, etc) within a distance of min. 0.5m.

Mount the projector with the mounting bracket to your trussing system using an appropriate clamp.

For overhead use, always install a safety-rope that can hold at least 10 times the weight of the fixture. You must only use safety –ropes with quick links with screw cap. Pull the safety-rope through the hole in the mounting bracket and over the trussing system or a safe fixation spot. Insert the end in the quick link and tighten the safety screw. The maximum drop distance must never exceed 20cm

A safety rope which already held the strain of a crash or which is defective must not be used again.

DANGER TO LIFE!

Truss Mate 2

Before taking into operation for the first time, the installation has to be approved by an expert.

1.2. Power Connection

!! CAUTION !!

Never leave this device running unattended!! Every person that is involved with this item has to be qualified!!

Connect item with main plug. The voltage and frequency must exactly be the same as stated on the device. The power plug must always be inserted without force.

1.3. Cleaning and Maintenance

Please make sure that safety-relating and machine-technical installations are inspected by a skilled person once a year.

1. Make sure before installing that all screws are tightly connected and not corroded.
2. There must be no deformations on the housings, fixations and installations spots
3. No damages must be showed on the power supply cables, material fatigue and sediments

If the exterior of the unit is going to be cleaned, please use moist, lint free cloths. Never use alcohol or solvents.

The Cooling fan must be cleaned monthly and check to ensure it is free of obstructions.

To clean the interior of the device please use a vacuum cleaner or an air jet, however we recommend cleaning the lenses weekly to ensure the best output from your unit.

Truss Mate 2

2.0 Menu navigation

NO.	Menu Level 1	Menu Level 2	Menu Level 3	Remark
1	3 - C H	d 1 d 5 1 2		Default: 3-CH, d 1
2	8 - C H	d 1 d 5 1 2		
3	C - -	C 1 C 2 C 3 C 4 C 5 C 6 C 7		1: R 2: G 3: B 4: GB 5: RB 6: RG 7: RGB (Default : RGB)
4	P - -	P 1 P 2 P 3 P 4		P1: 3Colors snap (Default P1) P2: 3 Colors Fade P3: 7Colors snap P4: 7Colors Fade
5	S - -	S - - 1 S 1 0 0		Speed : 1-100 (slow - fast) Default:100
6	S n d	S n d 1 S n d 2		Sound (Default: Snd1)
7	S e n S	u 0 u 1 0 0		(Default 80)
8	U - -	r 0 2 5 5 g 0 2 5 5 b 0 2 5 5		(Default RGB=255)
9	d I M	O F F d I M 1 d I M 2 d I M 3		OFF: Dimmer speed off DIM1: Dimmer speed fast DIM2: Dimmer speed middle DIM3: Dimmer speed slow Default: OFF

Truss Mate 2

10	S E T	O n	Default: On
		O F F	

3.0 DMX Allocation


3-CH	Function	Value	Percent/Setting
1	Red	000-255	0~100%
2	Green	000-255	0~100%
3	Blue	000-255	0~100%
8-CH	Function	Value	Percent/Setting
1	Red	000-255	0~100%
2	Green	000-255	0~100%
3	Blue	000-255	0~100%
4	Color	000-015 016-255	No Function Color Macros
5	Strobe	000-015 016-255	No Function Strobe Slow to Fast
Programs Speed		000-255	Programs Speed Slow to Fast
6	Programs	000-031 032-063 064-095 096-127 128-159 160-191	No Function 0-100% 100%-0 100% -0-100% Colors Fade 3Colors snap

Truss Mate 2

		192-223 224-255	7Colors snap Sound Control
7	Dimmer	000-255	0~100%
8	Dimmer speed mode	000-051 052-101 102-152 153-203 204-255	Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)

Truss Mate 2

4.0 TECHNICAL SPECIFICATIONS



Color	1m	LUX	3m	LUX	5m	LUX	7m	LUX	10m	LUX
R	1049		115		45					
G	1767		187		74.3					
B	250		27.1		10.6					
A										
W										
P										
RGB	3024		311		114					
RGBA										
RGBW										
RGBAWP										

Please note: Information is subject to change without prior notice ©

Power supply: 100 -240 V AC, 50/60 Hz ~

Fuse:T1A 250V

Power consumption: 13.6 W

Light Source: LED 3 IN 1 (3W 140°)

Beam Angle: 16°

Charging time 4.5h

Discharge: 6h (full Power)

Dimensions (LxWxH): 121.3 x 108.3 x 135.5 mm

Weight: 1.29kg

Maximum ambient temperature Ta: 45° C

Maximum housing temperature TC (steady state): 50°

Please note: Information is subject to change without prior notice ©